



**Engine's Dowel & Bearing Guide for Lycoming Engines**

Configuration	Cubic Inches	Quantity/ Nose Bearings	Quantity/ Main Bearings	Quantity	Quantity	Quantity	Quantity
				SL-10647 Straight	SL69796 LW-10734 Stepped	67453 Stepped Collar	LW-14450 Straight- Collar**
O	235/290	1 / 61533 1 / 61520	6 / SL68763A (with Prop Governor)				
O	235/290	2 / SL68763A	6 / SL68763A (without Prop Governor)				
O	235	2 / SL13884A	4 / SL68763A		2		
O/IO/LIO/AIO/AEIO	320	2 / SL13884A	4 / SL11020	4	2		
O/IO/LIO/AIO/AEIO	320	2 / SL16711A	6 / SL16711				
O/IO/LIO/AIO/AEIO	320	2 / SL13884A	4 / SL10124		2	4	
O/IO/LIO/AIO/AEIO	320	2 / SL68763A	6 / SL68763A		8		
O	340	2 / SL13884A	4 / SL11020	4	2		
O	340	2 / SL13884A	4 / SL10124		2	4	
O/LO/TO/LTO/IO/LIO/TIO/HO/ /HIO/LHIO/AEIO/AIO/VO/IVO	360	2 / SL13884A	4 / SL11020	4	2		
O/LO/TO/LTO/IO/LIO/TIO/HO/ /HIO/LHIO/AEIO/AIO/VO/IVO	360	2 / SL16711A	6 / SL16711A				
O/LO/TO/LTO/IO/LIO/TIO/HO/ /HIO/LHIO/AEIO/AIO/VO/IVO	360	2 / SL13884A	4 / SL10124		2	4	
O/LO/TO/LTO/IO/LIO/TIO/HO/ /HIO/LHIO/AEIO/AIO/VO/IVO	360	2 / SL68763A	6 / SL68763A		8		
GO/GSO/VO/TVO	435		8 / SL68763A			8	
GO/GSO/IGSO/VO/TIVO	480		8 / SL11020	8			
O/IO/IGSO/HIO/TIO/TVO/TIVO/AEIO	540	2 / SL13884A	6 / SL11020	6	2		
O/IO/IGSO/HIO/TIO/TVO/TIVO/AEIO	540	2 / SL16711A	8 / SL16711A				
O/IO/IGSO/HIO/TIO/TVO/TIVO/AEIO	540	2 / SL13884A	6 / SL10124		2	6	
O/IO/IGSO/HIO/TIO/TVO/TIVO/AEIO	540	2 / SL68763A	8 / SL68763A		10		
O/IO/IGSO/HIO/TIO/TVO/TIVO/AEIO	540	2 / 18A19399	6 / SL11575A	6	2		
TIO	541	2 / 74801	6 / 74303		8		
TIO	541	2 / 74801	6 / SL11575A	6	2		
TIGO	541		8 / SL11575A	8			
IO	720	2 / 18A19399	8 / SL11575A	8	2		

\*\* Straight Collered Dowells are used with either SL11020 (Small Bore Crank) or SL11575A (Large Bore Crank)